

USER'S MANUAL

Low temp cut off protection(Charge/Discharge)

12.8V 460Ah

LiFePO4

APP Connection



CATALOGUE

- 01 ● PRODUCT INTRODUCTION
- 02 ● ADVANTAGE
- 03 ● WARRANTY POLICY
- 04 ● CHARGING TIPS
- 05 ● LONG-TERM STORAGE
- 06 ● CONNECTION TIPS
- 07 ● ABOUT OUR BATTERY'S BMS
- 08 ● PRECAUTIONS
- 09 ● DISCHARGE CURVE
- 10 ● APPLICATION
- 11 ● OPERATION INSTRUCTIONS OF APP

01 / PRODUCT INTRODUCTION

LiFePO4 Battery	12.8V 460Ah
Nominal Voltage	12.8V
Charge Voltage	14.2V-14.6V
Weight	47.5KG / 104.7LB
Energy	5888Wh
Max Continuous Charging Current	300A
Max Continuous Discharging Current	300A
Recommend Charge Current	92A (0.2C)
Max Load / Inverter Power	3840W
Operating Temperature Range	Charge 0°C~50°C(32°F~122°F) Discharge -20°C~60°C(-4°F~140°F) Storage -10°C~50°C(14°F~122°F) Low temp cut off protection (Charge) 0°C ± 4°C (32°F ± 7.2°F) Low temp cut off protection (Discharge) -20°C ± 4°C(-4°F± 7.2°F)
Terminal Type	M8
Dimension	477*273*252mm 18.78*10.75*9.92inch

02 / ADVANTAGE

- Mobile with carry handles makes it easy to lift and move around.
- With a battery management system enclosed, needs no extra wiring.
- Built with LiFePO4 battery cells that are engineered to deliver superior performance & longevity.

- Battery voltage stays above 12.5V at 90% discharged.
- Maintenance Free; Nonspill.
- Perfect replacement or upgrade for a traditional lead-acid battery.

03 / WARRANTY POLICY

Disclaimer: We are not responsible for any accidents caused by non-compliance with the instructions specified in the user manual.

Warranty Service: This product comes with a VATRER POWER' s warranty from the date of manufacture. During the warranty period, if you encounter any problems, please feel free to contact us. Our after-sales service team will provide specific maintenance solutions and troubleshooting methods.

Warranty Details: For specific warranty details, please visit our official website at www.vatrerpower.co.za.

04 / CHARGING TIPS

► About Charging Voltage

Based on the characteristics of Lithium Iron Phosphate (LiFePO₄) batteries, the voltage measured by all LiFePO₄ batteries is not the real voltage of the battery.

Therefore, after charging and disconnecting the battery from the power source, the voltage of the battery will gradually drop to its real voltage. If you need to test the real voltage of the battery, please charge and disconnect the power supply and test its voltage after putting it aside for over 15 minutes.

► Charging Methods

Scheme 1: You can use a lithium iron phosphate 4-string (14.6V) charger to charge the battery pack.

Scheme 2: You can use photovoltaic solar panels to charge the battery through MPPT.

Scheme 3: You can use the inverter to charge the battery pack (note: the inverter needs a built-in AC to DC charging function)

Battery Charger

Use a 14.6V lithium battery charger to maximize the capacity. Recommend Charging Voltage: Between 14.2V to 14.6V.

92A(0.2C) The battery will be fully charged in around 5hrs to 100% capacity.

If you use an inverter (MPPT) to connect our battery pack, please refer to the following data:

The MPPT settings of the 12.8V lithium iron phosphate battery are as follows:

Select "12V (14.6V) LI (LiFePO4) Mode" or
Select "User Mode" to enter values according to below parameters:

	Parameter	Voltage/Time
Charging	Charging Limit Voltage	14.6V
	Over Voltage Disconnect Voltage	15V
	Over Voltage Reconnect Voltage	14.2V
	Equalizer Charging Voltage	14V
	Float Charging Voltage	13.8V
	Boost Charging Voltage	13.8V
	Boost Reconnect Charging Voltage	13.2V

	Parameter	Voltage/Time
Discharging	Low Voltage Disconnect Voltage	10.8V
	Low Voltage Reconnect Voltage	12.4V
	Under Voltage Warning Voltage	11.6V
	Under Voltage Warning Reconnect Voltage	12V
	Discharging Limit Voltage	10.4V
	Over Discharge Disconnect Voltage	10.4V
	Over Discharge Reconnect Voltage	11.6V
	Over-Discharge Delay Time	0.8s
Others	Equalize Duration	120min
	Boost Interval	Not suitable for lithium batteries
	Boost Duration	120min

05 / LONG-TERM STORAGE

- The battery can be operated at temperatures of -20°C to 60°C, and a temperature between 10°C to 35°C is ideal for long-term storage.
- Store in a fireproof container and away from children.
- For a longer-lasting product, it is best to store your battery at a 50% charge level and recharge every three months if it is not going to be used for a long period of time.

06 / CONNECTION TIPS

The premise of Connection: To connect in series or in parallel, batteries should meet the below conditions:

1. The same battery capacity (Ah);
2. From the same brand (as lithium batteries from different brands has their special BMS);
3. Purchased in near time (within one month).

► About connected in parallels and in series

Our LiFePO₄ batteries can be connected in parallel and in series for larger capacity and higher voltage. We suggest that the Max connection in series is: 4 pcs batteries to 48V, the Max connection in parallels is: it can connect multiple batteries, and no more than 10 pcs in parallel. Products of different manufacturers cannot be connected in series or in parallel. When the batteries are used in parallel or series, the voltage must be the same.

! Attention

When The Battery Is Discharging, The Switch Must Be Turned ON.

Battery Drawing




ON/OFF



Please refer to the following picture for the series connection



Please refer to the following picture for a parallel connection



► Two Necessary Steps Before Connecting:

These two steps are necessary in order to reduce the voltage difference between batteries, and through these, the battery system can perform the best of it in series or/ and in parallel.

Step1.

Fully charge your batteries separately.

Step2.

Connect your batteries one by one in parallel, and leave them together for 12~24 hours.

And then, you can connect your batteries in series or/ and in parallel.

07 / ABOUT OUR BATTERY'S BMS

The unique built-in battery management system (BMS) of our product's lithium battery can protect it from overcharge, deep discharge, over-load, overheating and short circuit, and low self-discharge rate. Our BMS has a high-temperature disconnect function. When the internal temperature of the battery reaches 75 °C (167 °F), It will automatically disconnect to protect the battery. With overcharge and over-discharge protection functions, when the overcharge voltage exceeds 15V or the over-discharge voltage is lower than 8.8V, the battery will automatically disconnect. Our recommended charging voltage and discharging voltage are $14.4 \pm 0.2V$ and $10V \pm 0.2V$, respectively. If the charging voltage is lower than 13.8V, the battery power(with a deviation of 1-2%) cannot be fully charged.

HOW TO ACTIVATE THE BATTERY WHEN BMS CUT IT OFF FOR PROTECTION?

If the BMS has cut off the battery for protection, you need to cut off the load of the battery and put the battery aside for 30 minutes. Then the battery will automatically recover itself to normal voltage and can be used after fully charged.


If the battery is unable to recover itself and its voltage is too low to hold a charge, you can activate it in below two ways:

1. Use the charger with 0V charging function (it can charge the battery starting from 0V) to charge the battery. After fully charged, the battery can be used normally.
2. Use another 12V lithium battery to connect in parallel with the battery for a minute to activate the battery (a lead-acid battery with a voltage more than/equal to 12V and less than/equal to 14.6V will also work). After that, fully charge the battery and it can be used normally.


08 / PRECAUTIONS

- When recharging, use the LiFePO4 battery charger specifically for that purpose.
- Do not strike the battery with any sharp edge parts, such as Ni-tabs, pins, and needles.
- Do not immerse the battery in water and seawater.
- Do not use and leave the battery near a heat source such as a fire or heater.
- Do not reverse the position and negative terminals.
- Do not connect the battery to an electrical outlet.
- Do not discard the battery in fire or heat it, and do not bend the tab.
- The battery tabs are not so stubborn, especially for aluminum tabs.
- Do not short-circuit the battery by directly connecting the positive and negative terminals with a metal object.
- Do not transport and store the battery together with metal objects such as necklaces, hairpins, etc.


Different Rate Discharge Curve (25°C)




Different Temperature Discharge Curve (0.5C)




State Of Charge Curve (0.5C , 25°C)




Charging Characteristics (0.5C , 25°C)



Different DOD Discharge Cycle Life Curve (0.5C)



Different Temperature Self-Discharge Curve







10 / APPLICATION

- RV, Camper, Trailer, Caravan, Camping Truck, Bus, etc.
- Solar System+ Wind Power System
- Home Energy System
- Boat& Fishing
- Wireless Lawn Movers, Vacuum Cleaners & Washing Machine
- Portable Video Camera& Portable Personal Computer
- Car Audio System
- Light Equipment
- Emergency Lighting Equipment
- Fire Alarm& Security Systems
- Electric Equipment& Telemeter Equipment Portable
- Toys& Consumer Electronics

11 / OPERATION INSTRUCTIONS OF APP

1. Search VATRER in the Android App Market or Apple App Store, then install VATRER app on your smartphone.
2. The system automatically searches for the Bluetooth that can be connected, find the battery Bluetooth number corresponding to the options in the list, and click "connect".
3. After the connection is completed, the current information of the battery will be displayed.
4. The bottom of the interface from left to right Bluetooth, Dashboard and About.





VATRER



www.vatrerpower.co.za